


Date: Sep 1st
2017

Class Problem
ABE 307
Micro-Manometer

- The micromanometer illustrated in figure below is a useful device for accurately measuring small pressure difference. If the densities of the two manometer fluids are nearly the same ($\rho_1 \approx \rho_2$), measurable values of the distance d can be obtained for very small values of the pressure difference, $P_B - P_A$. Letting A_1 be the cross-sectional area of the reservoirs, and A_2 be the cross-sectional area of the connecting tube, derive an expression for $P_B - P_A$ in terms of ρ_1 , ρ_2 , g , A_1 , A_2 and d .



$$P_{2,A} = P_A + \rho_1 g (l + \delta)$$

$$P_{2,B} = P_B + \rho_1 g (l + d - \delta)$$

To eliminate $P_{2,A}$ and $P_{2,B}$, find relationship between $P_{2,A}$ & $P_{2,B}$

$$P_{2,B} = P_{2,A} + \rho_2 g d$$

$$P_B - P_A = (\rho_2 - \rho_1) g d + 2 \rho_1 g \delta$$

→ compared to one liquid here you have two measurable quantities. d & δ , d is easier to see.


There were two interesting questions on micromanometer in class today

1. Why do we use two different liquids ?
2. Why should the density of two liquids be close i.e the density different is small.

Answer 1 : We use two different liquids to improve sensitivity, as you can derive the equation for using only liquid 1 and it will only be in terms of δ which will be difficult to observe while it will be easier to observe the interface of two liquids in terms of length d .

Answer 2 : The answer to this question is in the expression of $P_B - P_A$ for two different liquids written before. If you have liquids with large density difference, for same $P_B - P_A$ you will have less d which will be difficult to observe. So keeping the density difference of liquids lower, increases the length " d " that you can easily observe for smaller pressure difference.

Hence, use of two liquids and liquids of similar density is to be able to have highly sensitive micromanometer.



$$P_{2A} = \rho_1 g \delta + P_A \quad \text{--- (1)}$$

$$P_{2B} = P_B - \rho_1 g \delta \quad \text{--- (2)}$$

$$P_{2A} = P_{2B} + \rho_1 g \delta \rightarrow \text{--- (3)}$$

$$P_B - P_A = \rho_1 g \delta$$

from ① & ② $P_{2A} - P_{2B} = 2\rho_1 g \delta + (P_A - P_B) - \textcircled{4}$ Date:

from ③ $P_{2A} - P_{2B} = \rho_1 g \delta$

Substituting in ④

$$\rho_1 g \delta = 2\rho_1 g \delta + (P_A - P_B)$$

$\Rightarrow \boxed{P_A - P_B = \rho_1 g \delta} \rightarrow$ This was intuitive as well.

But the equation with only one liquid only shows $\boxed{\delta}$ as measurable quantity

It will be difficult to read the liquid displacement for small Pressure difference.